## **KCNET Protocol Version 1.2**

## **Commands PIO-Communication (binary)**

| Command                               | Number | Byte 1      | Byte 2                               | Byte            | Answer                                |
|---------------------------------------|--------|-------------|--------------------------------------|-----------------|---------------------------------------|
| Write Bytes to Pointer+ (8000H+)      | 0      | lowCounter  | highCounter                          | Counter * Bytes | -                                     |
| Read Bytes from Pointer+              | 1      | lowCounter  | highCounter                          |                 | Counter * Bytes                       |
| Write Address-Pointer for Command 0/1 | 2      | IowAddress  | highAddress                          |                 | -                                     |
| Read Timer                            | 3      |             |                                      |                 | Byte Tlow, Byte Thigh                 |
| Write Byte to address (8000H+)        | 4      | IowAddress  | highAddress                          | Byte            | -                                     |
| Read Byte from address                | 5      | IowAddress  | highAddress                          |                 | Byte                                  |
| Write IP-Address 07                   | 6      | Number (07) | 4 Byte IP Net-Order (b4, b3, b2, b1) |                 | <u>-</u>                              |
| Read IP-Address 07                    | 7      | Number (07) |                                      |                 | 4 Byte IP Net-Order (b4, b3, b2, b1)  |
| Read Dynamic Port Number              | 8      |             |                                      |                 | 2 Byte Port Number Net-Order (b2, b1) |
| Read SW-Version                       | 9      |             |                                      |                 | Byte MINOR, Byte MAJOR                |
| Read HW-Version                       | 10     |             |                                      |                 | Byte MINOR, Byte MAJOR                |
| Read Link State                       | 11     |             |                                      |                 | Byte                                  |
| Read Identity String                  | 12     |             |                                      |                 | String + 0 (max. 128 Byte)            |
| Read Command Errors                   | 13     |             |                                      |                 | Byte Elow, Byte Ehigh                 |

## Commands RS232-Communication (ASCII, 1 SPC between ARG's)

| Command                               | CMD   | Arg 1       | Arg 2     | Arg       | Answer                                |
|---------------------------------------|-------|-------------|-----------|-----------|---------------------------------------|
| CLS & Help                            | ENTER |             |           |           | display Help-Screen                   |
| Read ID                               | k     |             |           |           | Message                               |
| Read Config                           | С     |             |           |           | Message                               |
| Read SW-Version                       | s     |             |           |           | Message                               |
| Read HW-Version                       | h     |             |           |           | Message                               |
| Read Link State                       | 1     |             |           |           | Message                               |
| Write Byte to address                 | w     | Address hex | Byte hex  |           | Address=Byte                          |
| Read Byte from address                | r     | Address hex |           |           | Byte                                  |
| Write Address-Pointer for Command x/y | р     | Pointer hex |           |           | Pointer                               |
| Write Bytes to Pointer+               | X     | Counter hex | Counter * | Bytes hex | Bytes of Counter (Address to Address) |
| Read Bytes from Pointer+              | у     | Counter hex |           |           | HEX- & ASCII-Dump Bytes               |
| Debug PIO-In on/off                   | i     |             |           |           | Message new State                     |
| Debug PIO-Out on/off                  | 0     |             |           |           | Message new State                     |

## **Restrictions of the PIO-Interface**

- locking conditions with PIO-Output as well as PIO-Input are broken off by 524 ms and the complete command-processing puts back in normal state
- PIO has only on addresses of the TCP/IP-Stack writing-access (8000H ... FFFFH)
- PIO cannot write the Ethernet-MAC-Address of the TCP/IP-Stack (8009H ... 800EH)